



COLD WATER TANK JACKETS



DESCRIPTION:

The CCL range of cold water tank lagging jackets consist of lengths of light weight glass wool insulation that has been completely enclosed in black perforated polythene.

PURPOSE:

Cold water tank lagging jackets are designed to help protect cold water storage tanks in traditional domestic lofts against freezing.

BENEFITS:

- Two piece lagging jacket
- Helps protect against freezing
- Easy to install
- Meets requirements of Bylaw 30
- Rigid or flexible lid

Specification

Dimensions



The range of lagging jackets are manufactured in sizes to suit the tank sizes detailed in the chart below. The lagging jackets are supplied with or without a rigid lid insert. Lagging jackets to suit bespoke tanks are available upon request.

Rectangular Tanks	Tank Size L x W x H (inches)
10/4	18 x 12 x 12
20/15	26 x 21 x 17
30/20	27 x 21 x 20
40/25	29 x 23 x 21
60/40	40 x 25 x 24
70/50	46 x 25 x 24

Circular Tanks	Tank Size Dia x H (inches)
4 gallon	19 x 11
25 gallon	27 x 21
50 gallon	33 x 25
70 gallon	38 x 27
100 gallon	42 x 30

Standards & Performance:



CCL cold water tank lagging jackets are designed to aid compliance with Water Byelaw 30 which calls for cisterns storing water for domestic purposes to be insulated against heat and frost.

Specification:



The CCL range of cold water tank jackets are manufactured using a low density, flexible, glass wool insulation that is manufactured to BS3533:1981. The insulation is non-combustible, classified as Euroclass A1 to BS EN ISO 13501 - 1.

The thermal conductivity is 0.040W/mK.

The outer covering is manufactured from 38 micron, micro perforated polythene film which encourages good recovery of the insulation from any compression that may have occurred during packaging and transportation.

Each jacket is individually wrapped and comes complete with two lengths of nylon ribbon and a label clearly displaying the tank size and easy to follow instructions.




Installation:

CCL tank jackets are supplied in two pieces with separate fixing tapes.

Unroll the long flexible panel and shake gently to allow the insulation filling to recover. Position the panel around the body of the tank, allowing for pipes and fittings, and secure with the coloured fixing tapes as illustrated. Be careful not to over tighten so the insulation is not compressed.

Place the lid panel on to the tank lid and tuck in the flanges carefully, ensuring there are no gaps around the edge of the tank.



sales@concept-conversions.co.uk



01933-673100



www.concept-conversions.co.uk



Unit 13, Trinity Centre,
Park Farm Industrial Estate,
Wellingborough, Northants,
NN8 6ZB.

